https://pchub.com/toshiba-tecra-l2-series-indicater-board-switch-button-cover-36ew3ka0052-p62190

Toshiba Tecra L2 series Indicater Board Switch / Button Cover 36EW3KA0052

Model / GTIN	Tecra L2 series
Item Condition	Used
Part Description	Cover For On/Off Switch & Shortcut Button Board
Part Number	36EW3KA0052, EAEW3003014
Warranty	1 Month(s)